


Monarch Water Ltd, Halesworth Road, Bramfield, Halesworth, Suffolk, IP19 9HP. If you would like assistance or to find out more about Monarch Water products please call us on 01986 784759 (Mon-Fri 8.30am-5pm) email us: sales@monarchwater.co.uk

Typical TWS MainsBoost Accumulator Installation on mains supply with Water Softener


Air charge pre- set at 1.4 bar differential 1.6-1.9 bar below mains or pump pressure setting



Commerce House 45 Northgate Morecambe Lancs LA3 3PA Tel 0333 121 3050 – Info@twsuk.com

Monarch Water Ltd, Halesworth Road, Bramfield, Halesworth, Suffolk, IP19 9HP. If you would like assistance or to find out more about Monarch Water products please call us on 01986 784759 (Mon-Fri 8.30am-5pm) email us: sales@monarchwater.co.uk

Typical TWS MainsBoost Plus Installation on mains supply with Water Softener




Commerce House 45 Northgate Morecambe Lancs LA3 3PA Tel 0333 121 3050 – Info@tw suk.com

Monarch Water Ltd, Halesworth Road, Bramfield, Halesworth, Suffolk, IP19 9HP. If you would like assistance or to find out more about Monarch Water products please call us on 01986 784759 (Mon-Fri 8.30am-5pm) email us: sales@monarchwater.co.uk

Typical TWS MainsBoost Accumulator and charger pump Installation on mains supply with Water Softener

Air charge pre- set at 1.4 bar differential 1.6-1.9 bar below mains or pump pressure setting



Commerce House 45 Northgate Morecambe Lancs LA3 3PA Tel 0333 121 3050 – Info@twsuk.com